

## Installation of HL-SERVER dongle

For the usage of a "Floating" licence model with QMSOFT a special HL-SERVER dongle has to be used, which is controlled by a special licence managing software driver.

As the local dongles also the HL-SERVER-dongle is available for connecting to the parallel port or to the USB-port of the computer, which should be used as the „licence server“. In most cases it will be a really server, but it is also possible to use a normal „workplace computer“ as licence server in the network, which is switched on permanently.

On the client side all of the driver software will be installed automatically by the QMSOFT installation procedure itself.

On the „licence server computer“ an additional driver software has to be installed manually. The „licence server computer“ is the machine, where the HL-SERVER-dongle is connected to.

The HL-SERVER-software should be installed as a service. The installation has to be done by executing the program file "**HLSW32.EXE**". This file can be found at the QMSOFT-CD-ROM in the folder "**Additional\Hardlock**".

Please note also the more detailed manual of the manufacturer of the HL-SERVER-Dongle (Aladdin) in the folder "**Additional\Hardlock**", but it is available only in German („hlendkundenhandbuch\_ge.pdf“).